- ful 2nd ha Subject: Numbering Plan for BSP Divisions 190, 201, 212, 205V. 216, STAFF SUPPTER OF

218, 220, 226, 233 and 333.

December 2, 1977

77-12-004

OW. FLT. MGA. DIV. PLT. SUPV. - DIV -PLT - STAFF SUPV DIV. PLT. STAFF & DIV. P. T. STAFF DST. PLT. MGR. DST: FLT. MGR. AHLITEHUSON and DST. PLT. MGR. TEIGRED MS. pany. DST. PLT. MGR. MARCHINAVCENTRAL-IAR DST. PLT. MGR. WYCPHT'N EAS DST. PLT. MGR.

ю: General Network Managers, General Switching Managers BURN TO: General Plant Managers and BSP Coordinators DIV. PLT. MGR. - WICHITA

from: Director - Network Maintenance

synopsis: Advises of the establishment of additional uniform numbering methods in BSP Divisions; 190, 201, 212, 215, 216, 218, 220, 226, 233, and 333 and provides a list of renumbered Sections.

GL 77-05-262 announced plans to convert Traffic Facility Practices (TFPs) and Dial Facility Management Practices (DFMPs) to the 9-Digit Series of Bell System Practices in order to achieve improvements in the preparation, distribution, availability and use of these documents.

Planning for this conversion has resulted in the establishment of additional uniform numbering methods in certain BSP Divisions. Attachment 1 provides a list of the involved Divisions and explains the additional standard arrangements.

As a result of these new standard arrangements, it has been necessary to renumber a few existing Sections which are not currently scheduled for text revision and reissuance in the near future. Attachment 2 provides a "New" and "Cancelled" cross reference list.

These Sections will be renumbered by issuing a single-sheet cover page of gold paper (See Attachment 3); all will be Issue 1. The cancelled Section number will be retained in it's Division Index for a 12 month period and will be marked by a special symbol; i.e. open-star . A note will be provided to cross reference to the new Section number. Issue 2 of these Sections will be handled in the normal manner. Requisitions for the renumbered Sections which incorrectly use the old number will be filled for a six months period only.

Operating Telephone Company BSP coordinators have been previously advised of these changes and are taking the necessary steps to assure the proper distribution of the new-number face sheets. Standard distribution will occur in the first quarter of 1978.

NOTICE

Not for use or disclosure outside the Bell System except under written agreement. Questions may be directed to L. A. Ratliff, Network Maintenance on 201-221-4729.

L. J. year

Director - Network Maintenance

Attachments: 1. Numbering Plan

2. BSP Crossreference list

3. Sample of BSP Cover Page

NUMBERING PLAN

Divisions Involved:

190	Operations Support Systems - Operation Maintenance Administration
201-	Supplemental Information - Central Offices

No. 4A and 4M Toll Switching Systems 212-

215-Panel Offices

216-No. 1 Crossbar Offices

218-No. 3, No. 5, and No. 5A Crossbar Offices

220-Crossbar Tandem Offices

226-Equipment Common to More than One Type Step-by-Step and Community Dial Office .

233-No. 3 Electronic Switching System (ESS)

333-Interoffice Signaling Systems

The 9 digit number configuration - XXX-YYY-ZZZ

XXX = Division number

YYY = Layer

-020-522

ZZZ = Key number

Plan for 190

190-000-zzz	Indexes	
-001-ZZZ	Equipment Test Lists	
-010-ZZZ	General Information - OSS Systems	
-020-zzz	Network Operations (Administration and Maintenance) General OSS Methods	-
-020-0ZZ	Network Operations - General Common Methods	

Network Maintenance - General OSS Operation and Maintenance .Administration

190-YYY-

-200-10Z

In general, a single unique layer number will be assigned to each separate OSS. Operational Support Systems may include personnel subsystems which are not integrated with hardware or software systems. e.g., Network Service Center, Alarm Center etc.

Plan	for 201, 212,	215, 216, 218, 220, 226, 233
	XXX-000-ZZZ	Indexes
•	-001- ZZZ	Equipment Test Lists
	- 010-ZZZ	General Information
	-020-ZZZ	Network Operations (Administrative and Maintenance) - Methods
	-020-0ZZ	Network Operations - Common Methods
	-020-1ZZ	Network Administration - Line and Trunk Administration
	-020-2ZZ	Network Administration - Common Control Administration
	-020-3ZZ	Network Maintenance - Trunk Operation and
		Maintenance Administration
	-020-4ZZ	Network Maintenance - Terminal Equipment
		Operation and Maintenance Administration
-	-020-5ZZ	Network Maintenance - Machine Operation and
		Maintenance Administration
	-020-6ZZ	Network Maintenance - Line Operation and
		Maintenance Administration
	-040-222	Measurements
•	-060-ZZZ	Network Design
	-100-ZZZ	General System Information
Plan	for 333-200-	Interoffice Signaling Systems - CCIS
٠	333-200	Common Channel Interoffice Signalling System
•	333-200-01Z	General Information
. •	-200-02Z	Network Operations (Administration and Maintenance) - Methods
	-200-04Z	Measurements
	-200-06Z	Network Design

General System Information

1.

BSP Crossreference List

New ·	
Section Number	Cancelled
190-103-300	Section Number
-311	010-410-300
-311 -312	-311
-312 -313	-312
-313 -314	-313
-315	-314
-330	-315
330	-330
190-401-000	
-100	010-401-000
-110	-100
-120	-110
-1 30	-120
-140	-130
-1 50	-140
-200	-150
-2 10	-200
-220	-210
-230	-220
-240	-230
-250	-240
-300	-250
-320	-300
-330	-320
190-501-100	-330
-202	252-115-101
-203	-102
-204	-103
-205	-301
-211	~302
-212	-511
-213	-512
-214	-513
-215	-514
-216	-515
-221	-516
-222	-521
-223	-522
-540- 100	-523
-201	-116-101
- 202	-301
- 203	-302
-204	-303
	-501

Ness	Cancelled	
New	Section Number	
Section Number		
	201-112-001	
201-020-001	-005	
-002	-006	
-003	-010	
-010	-011	
-011	-012	
-012	-013	
-013	-014	
-014	-015	
-015	-020	
-020	-025	
-025	-026	
-026	-114-001	
-030	-114-001	
212-020-005	212-001-005	
-010	-041-010	
-310	010-420-101	
-530	212-702-301.	
-540	-050-101	
· -100-000	964-110-100	
	-310-100	
-001	-110-101	
-002	212-040-301	
-101-010	-012-100	
-020	-026-001	
-500-010	-027-001	
-700-010	•	
	215-010-302	
215-020-310	-001-010	
- 510	-010-301	
-610	020	
	216-001-005	
216-020-005	-105-301	
-610	-106-301	
-611	-107-301	
-612	-107-302	
-613	-107-302	
	218-001-005	
218-020-005	-100-301	
-605	-101-301	
-610	-101-301	
1	222 2/1 010	
220-020-010	220-041-010	
-530	-533-301	
-540	-025-101	
-1 00-000	960-110-100	
-001	-310-100	
-003	-320-100	
	220-013-301	
-120-301	-011-301	
-121-502		

New	Cancelled
Section Number	Section Number
226-020-005	226-001-005
-61 0	-100-100
-620	-135-300
-630	-140-300
-640	-155-300
333-200-021	010-430-501

.

0